



# DIN 988

## Paßscheiben




	h	0,1	0,15	0,2	0,25	0,3	0,5	1	1,2	1,5	2	2,5
d1	d2											
3	6											
4	8											
5	10											
6	12											
7	13											
8	14											
9	15											
10	16											
11	17											
12	18											
13	19											
14	20											
15	21											
15	22											
16	22											
17	24											
18	25											
19	26											
20	28											
22	30											
22	32											
25	35											
25	36											
26	37											
28	40											
30	42											
32	45											



# DIN 988

## Paßscheiben



d1	h	0,1	0,15	0,2	0,25	0,3	0,5	1	1,2	1,5	2	2,5	3	3,5
35	45													
36	45													
37	47													
40	50													
42	52													
45	55													
48	60													
50	62													
50	63													
52	65													
55	68													
56	70													
56	72													
60	75													
63	80													
65	85													
70	90													
75	95													
80	100													
85	105													
90	110													
95	115													
100	120													
100	125													
105	130													
110	140													
120	150													
130	160													
140	170													
150	180													
160	190													
170	200													